Samsung Portable Dualband Tri-Mode Battery Replacement

Use this guide to replace the battery of the Samsung Portable Dualband Tri-Mode phone.

Written By: Kali Kupp



INTRODUCTION

If the battery is dead, damaged or malfunctioning, the battery must be replaced. This guide outlines how to remove a malfunctioning battery for the Samsung Portable Dualband Tri-Mode phone.

Step 1 — Battery





- Slide the battery out from the battery compartment on the back of the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-07 12:04:31 PM.